

RPC-902 Quickstart Users Guide

FUNCTION: To select the operation mode push one of the FUNKTION buttons. Confirm your selection with TAKE or abort with any other button.

NORMAL MODE: Select your preview source on the PREVIEW panel. Put it in the program with TAKE or CUT(transition time = 0s). You can also perform a “PGM cut”. To do that, select your next source on the PROGRAM panel.

Push FRZ to freeze the program output.

MATRIX MODE: Select your next MX1-input / MX2-input on the PREVIEW / PROGRAM panel. Perform a TAKE or CUT transition. Accidentally chosen inputs can be deselected by pressing them again.

Push FRZ to freeze both MX OUT. To freeze a single MX OUT press and hold FRZ and then push an input of the MX OUT you want to freeze. Same procedure to unfreeze.

PIP MODE: Select your next PIP 1-input / PIP 2-input on the PREVIEW / PROGRAM panel. Perform a TAKE or CUT transition. Accidentally chosen inputs can be deselected by pressing them again.

To deactivate a PIP just push his active input. To activate it again press any input.

Push FRZ to freeze both PIPs. To freeze a single PIP press and hold FRZ and then push an input of the PIP you want to freeze. Same procedure to unfreeze.

To recall a preset, first there have to be presets saved on the PDS device. Press and hold the RECALL PRESET button. Now you can see the saved PIP presets on the PIP 1 and PIP 2 panel. Push the preset number you want to recall.